



Air Filters are designed to trap dirt and contaminants before they reach your engine, thereby reducing engine wear. Genuine Toyota Air Filters are engineered specifically for your Toyota to provide exceptional filtering efficiency, engine performance and noise-dampening capabilities. Features of Genuine Toyota Air Filters include:

- ✓ *Needle-punch construction and triple-layer filtering, which give Genuine Toyota Air Filters their superior ability to trap and retain dirt and dust.*
- ✓ *Polyurethane resin frames, which make for a better fit, helping seal out dirt and reduce vibration noise.*

Toyota recommends replacement of the engine air filter every 30,000 miles or 36 months. If you operate your Toyota under special operating conditions, Toyota recommends inspection of the filter every 15,000 miles or 18 months.

Don't Compromise the Quality of Your Toyota - Always Ask for a Genuine Toyota Air Filter.